

Errata - 500B Series Laser Diode Drivers Users Manual

1. Page 30

Section 4.2, The Model 500B Series rear panel shows the OUTPUT connectors, ~~a~~
~~REMOTE/LOCAL switch~~, the photodiode reverse voltage BIAS ADJUST...